

PORTAFILTRO PER CIALDA

Con regolazione automatica

Il portafiltro per cialda è uno strumento utile per godersi il proprio thè, orzo o tisana sfruttando la macchina da caffè professionale (è adatto anche per le cialde di caffè)



Come utilizzare il portafiltro:

- 2- Questo portafiltro è adatto per l'utilizzo con cialde monouso di caffè, thè, orzo, tisana e anche per orzo in grani
- 3- Inserire la cialda nell'apposita sede
- 5- Collegare il portafiltro alla macchina da caffè
- 4- Avviare l'erogazione
- 5- Il portafiltro avvia il flusso in uscita in modo automatico grazie ad una valvola posta all'interno del beccuccio. In questo modo si ha un risultato in tazza costante. E' possibile regolare il tempo di pre-infusione ruotando leggermente il beccuccio.
- 6- Completata l'erogazione scollegare il portafiltro dalla macchina
- 7- Lavare il portafiltro

Nota: Per ottenere un buon risultato in tazza si consiglia di riscaldare il portafiltro prima dell'uso.

Nella pagina seguente le istruzioni per la regolazione

POD PORTAFILTER

With automatic adjustment

With our pod portafilter you can enjoy tea, barley or herbal teas using your professional coffee machine (also for coffee pod)

CODE	MODEL
9V9100/C	CIMBALI
9V9100/F	FAEMA, AURORA BRUGNETTI, BRASILIA B61, CONTI
9V9100/SM	SAN MARCO
9V9100/SP	SPAZIALE
9V9100/W	WEGA, BFC-ROYAL, BIANCHI, CREM-EXPOBAR, GRIMAC, LA MARZOCCO, LA SCALA, RANCILIO, SANREMO, VIBIEMME

How to use the portafilter:

- 1- This portafilter is suitable for coffee pods, tea pods, barley pods and grains, herbal teas pods
- 4- Introduce the pod into the portafilter
- 3- Fix the portafilter on the coffee machine
- 4- Start brewing
- 5- The portafilter starts the flow in an automatic way using a valve inserted inside the spout. It is possible to adjust the pre-infusion time turning slightly the spout. In this way you can obtain a constant results in the cup.
- 6- At the end take off the portafilter from the machine.
- 7- Wash the portafilter

Note: If you want to obtain a better result, we advice you to pre-heat the portafilter before to use it.

In the next page the ordering codes and adjusting instructions

Regolazione altezza cialda

E' possibile effettuare una leggera regolazione della profondità della sede per l'inserimento della cialda. Per fare ciò è necessario eseguire le seguenti operazioni:

- rimuovere la molla il filtro all'interno del portafiltro
- svitare parzialmente il beccuccio
- utilizzare un cacciavite a taglio per ruotare in senso orario o anti-orario la sede del portafiltro fino a raggiungere l'altezza desiderata
- riposizionare il filtro e bloccarlo con la molla
- avvitare il beccuccio

Pod height adjustment

It is possible to make a depth adjustment to allow the insertion of different height pods.

Follow the instructions:

- remove spring and filter from the inside of the portafilter
- unscrew the spout
- using a screw driver turn left or right the base to increase or decrease the height of the inside until you reach the level you need
- put the filter and fix it with the spring
- screw the spout

